



Listening to the Radio (see Fig. F-①)

- 1 Press RADIO ON/BAND to turn on the radio.
- 2 Press RADIO ON/BAND repeatedly to select AM or FM.
- 3 Press TUNING +/- to tune in the desired station. If you keep pressing TUNING +/- for a few seconds, the Walkman will start tuning to the stations automatically.

To turn off the radio

Press ■(RADIO OFF).

To improve the broadcast reception

- For AM: The Walkman has a built-in antenna. Reorient the Walkman horizontally to obtain optimum AM reception.
- For FM (see Fig. F-②): Extend the cord of the remote control, the aerial. If the reception is still not good, press MENU repeatedly to set the cursor to FM MODE in the display. Then press SET to choose from "MONO" (monaural), "LOCAL" or none (stereo) mode for best reception.

Notes

- If you cannot complete step 3 or 4 while the indications are flashing, repeat from step 2.
- If you preset a new station to the same preset number, the previously stored station will be erased.

Using the Remote Control (see Fig. H)

All buttons on the remote control unless otherwise noted below function identically to those corresponding on the main unit. Read the direction for your model.

Note

- Do not remove the power sources while listening to the radio, or the received stations may not be stored.

Presetting Radio Stations

Once you store your favorite stations in memory, you can play them easily. You can preset up to 16 stations for FM and 8 stations for AM of each mode.

Tuning in and Storing Radio Stations Automatically (Auto-Memory Scanning function) (see Fig. F-③)

- 1 Press RADIO ON/BAND to turn on the radio.
- 2 Press RADIO ON/BAND repeatedly to select AM or FM.
- 3 Press ENTER until "A" appears in the display. The Walkman starts searching and storing stations.
- 4 After the preset number appears, tune in to a station using PRESET +/-.

Using SOUND (GX654 only)

Press SOUND/AVLS to select the desired mode. With each press, the indications change as follows:

MB (MEGA BASS) : emphasizes bass sound

GRV (GROOVE) : emphasizes deeper bass sound

No message: off (normal)

For GX654

When using the remote control, see "Using the remote control".

Note

• If the sound is distorted with the mode "GRV", select the mode "MB".

Using AVLS (GX654 only)

Press and hold SOUND/AVLS for two seconds or more. "□" appears in the display.

To cancel, press and hold SOUND/AVLS for two seconds or more again.

For GX652

HOLD indicator

Indicatore HOLD

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL

FF/REW+PRESET +/-

REC

HOLD

■(RADIO OFF)

BAND(RADIO ON/BAND)

VOL</p